



ADLINK
TECHNOLOGY INC.

AD-Logger

Configuration-based Data Logger

User's Manual

Manual Rev. 2.00
Revision Date: March 9, 2009
Part No: 50-11239-1000



Recycled Paper

Advance Technologies; Automate the World.



Copyright 2009 ADLINK TECHNOLOGY INC.

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Trademarks

LabVIEW and NI are registered trademarks of National Instruments, Inc.

All product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Getting Service from ADLINK

Contact us should you require any service or assistance.

ADLINK Technology Inc.

Address: 9F, No.166 Jian Yi Road, Chungho City,
Taipei County 235, Taiwan
台北縣中和市建一路 166 號 9 樓

Tel: +886-2-8226-5877
Fax: +886-2-8226-5717
Email: service@adlinktech.com

Ampro ADLINK Technology Inc.

Address: 5215 Hellyer Avenue, #110, San Jose, CA 95138, USA

Tel: +1-408-360-0200
Toll Free: +1-800-966-5200 (USA only)
Fax: +1-408-360-0222
Email: info@adlinktech.com

ADLINK Technology Beijing

Address: 北京市海淀区上地东路 1 号盈创动力大厦 E 座 801 室
(100085)
Rm. 801, Power Creative E, No. 1, B/D
Shang Di East Rd., Beijing 100085, China

Tel: +86-10-5885-8666
Fax: +86-10-5885-8625
Email: market@adlinktech.com

ADLINK Technology Shanghai

Address: 上海市漕河泾高科技开发区钦江路 333 号 39 幢 4 层
(200233)

Tel: +86-21-6495-5210
Fax: +86-21-5450-0414
Email: market@adlinktech.com

ADLINK Technology Shenzhen

Address: 深圳市南山区科技园南区高新南七道 数字技术园
A1 栋 2 楼 C 区 (518057)
2F, C Block, Bld. A1, Cyber-Tech Zone,
Gao Xin Ave. Sec 7, High-Tech Industrial Park S.,
Shenzhen, 518054 China

Tel: +86-755-2643-4858
Fax: +86-755-2664-6353
Email: market@adlinktech.com



ADLINK Technology Inc. (German Liaison Office)

Address: Nord Carree 3, 40477 Duesseldorf, Germany

Tel: +49-211-495-5552

Fax: +49-211-495-5557

Email: emea@adlinktech.com

ADLINK (French Liaison Office)

Address: 15 rue Emile Baudot, 91300 MASSY Cedex, France

Tel: +33 (0) 1 60 12 35 66

Fax: +33 (0) 1 60 12 35 66

Email: france@adlinktech.com

ADLINK Technology Japan Corporation

Address: 151-0072 東京都渋谷区幡ヶ谷

1-1-2 朝日生命幡ヶ谷ビル 8F

Asahiseimei Hatagaya Bldg. 8F

1-1-2 Hatagaya, Shibuya-ku, Tokyo 151-0072, Japan

Tel: +81-3-4455-3722

Fax: +81-3-5333-6040

Email: japan@adlinktech.com

ADLINK Technology Inc. (Korean Liaison Office)

Address: 서울시 강남구 논현동 60-12 동성빌딩 4층 402호

No.402, Dongsung B/D, 60-12, Nonhyeon-Dong

Gangnam-gu, Seoul, 135-010, Korea.

Tel: +82-2-2057-0565

Fax: +82-2-2057-0563

Email: korea@adlinktech.com

ADLINK Technology Singapore Pte Ltd.

Address: 84 Genting Lane #07-02A, Cityneon Design Centre,

Singapore 349584

Tel: +65-6844-2261

Fax: +65-6844-2263

Email: singapore@adlinktech.com

ADLINK Technology Singapore Pte Ltd. (Indian Liaison Office)

Address: No. 1357, "Anupama", Sri Aurobindo Marg, 9th Cross,

JP Nagar Phase I, Bangalore - 560078, India

Tel: +91-80-65605817

Fax: +91-80-22443548

Email: india@adlinktech.com

Table of Contents

| | |
|--|-----------|
| Table of Contents | i |
| 1 Introduction to AD-Logger | 1 |
| 1.1 What is AD-Logger? | 1 |
| 1.2 Features and Highlights | 1 |
| 1.3 Terminology | 2 |
| 2 Software Installation | 3 |
| 2.1 Where to Obtain AD-Logger | 3 |
| 2.2 Before You Proceed | 3 |
| 2.3 Installing AD-Logger | 4 |
| 2.4 Uninstalling AD-Logger..... | 6 |
| 2.5 Launching the AD-Logger..... | 6 |
| 3 Understanding AD-Logger | 7 |
| 3.1 Main Menu | 7 |
| File Menu | 7 |
| Task Menu | 8 |
| Setting Menu | 8 |
| Viewer Menu | 9 |
| Export Menu | 9 |
| Help Menu | 9 |
| 3.2 AD-Logger Function..... | 10 |
| Speed Buttons | 12 |
| Buffer Viewer | 13 |
| Task Explorer/Logged Data Viewer | 14 |
| Status Viewer | 17 |
| Data Viewer | 18 |
| Message Viewer | 22 |
| 4 Starting AD-Logger | 23 |
| 4.1 Configure a DAQ Task..... | 23 |
| Modify Task | 23 |
| Create Task | 28 |
| Delete Task | 30 |
| 4.2 Setting DAQ Condition..... | 31 |
| Display Settings | 32 |
| FFT setting | 33 |

| | | |
|----------|---|-----------|
| | Recording Condition | 34 |
| | Alarm condition | 35 |
| 4.3 | Start Data Acquisition | 36 |
| 4.4 | Stop and Export Data for post-processing | 38 |
| 5 | Exporting Functions | 39 |
| 5.1 | Export Data to Excel for post processing..... | 39 |
| 5.2 | Export Data as a CSV file for Excel for post processing.... | 41 |
| 5.3 | Export Data into LabVIEW for post processing..... | 43 |
| 5.4 | Export Data into DIAdem for post processing..... | 56 |
| 5.5 | Export Data into MATLAB post processing..... | 59 |
| 6 | Appendix..... | 69 |
| 6.1 | AD-Logger .DAT File Format | 69 |
| | DASK Header | 70 |
| | ChannelRange | 71 |
| | Data Block | 72 |
| | AD-Logger Header | 73 |
| | ChannelRange | 74 |

1 Introduction to AD-Logger

1.1 What is AD-Logger?

AD-Logger is a smart and easy-to-use data acquisition software that works with all ADLINK devices which equip with analog input and digital input function. AD-Logger provides an intuitive user interface that helps complete a data acquisition application in only four steps without any programming. Get started by defining a DAQ task with the DAQPilot interactive dialog; then configure the recording conditions, and start logging for online analysis or export the data for offline analysis and post processing



1.2 Features and Highlights

- ▶ Logs data based on DAQPilot task configurations
- ▶ Supports both real-time and historical viewers
- ▶ Supports intuitive user interface as a ready-to-run application
- ▶ Supports data exporting functions for offline analysis in third party applications, including Microsoft Excel, NI® DIADem, and Mathworks MATLAB®
- ▶ Supports all ADLINK DAQ hardware
- ▶ Provides basic analysis functions, such as FFT
- ▶ Provides monitoring features via a user-friendly toolbox
- ▶ Provides a buffer monitoring mechanism to automatically evaluate the system performance to know if the captured data can be processed in real-time

1.3 Terminology

Below are some of the terms used in this document.

| Word | Description |
|------------------|---|
| DAQ | Data acquisition. The capture or collection of data. |
| Task | A DAQ task is a complete set of parameters including channels, timing, and trigger properties. A DAQ task represents a type of measurement that you want to perform. You can easily create task, modify task and delete task in AD-Logger. |
| Tracking | The tracking function is embedded in the DataView for you to easily trace captured data. When the tracking function is enabled, the axes will adjust their min and span values based on the tracking style. In addition to enabling tracking, all cursors will be hidden, and the axes min and span will be restored to their previous values when the axes tracking were initially disabled. |
| DAQPilot | DAQPilot is a task-oriented DAQ driver comes with an intuitive wizard to assist you in developing cutting-edge DAQ applications in an instant. |
| Buffer Mechanism | AD-Logger provides a buffer evaluation mechanism to monitor system performance of data acquisition in real-time. |
| Export | Output data function. You can convert the logged files to other data formats for the further processing. |
| FFT | Fast Fourier Transform. AD-Logger provides FFT power spectrum analysis. |
| Log | Data logging is the practice of saving DAQ data to hard drive. |

Table 1-1: Terminology

2 Software Installation

This section provides the installation information before you start to use AD-Logger software.

2.1 Where to Obtain AD-Logger

The AD-Logger evaluation version is available on the All-In-One CD that comes in your DAQ card package. You can also download the latest evaluation version from the ADLINK website through the following URL: <http://www.adlinktech.com/MAPS/AD-Logger.html>.

2.2 Before You Proceed

Before you starting to use AD-Logger software, make sure your system meets the following requirements.

System Requirements

- ▶ Windows 98/NT/2000 or 32-/64-bit editions of Windows XP/Server 2003/Vista operating system
- ▶ Intel Pentium-class CPU or higher
- ▶ VGA display or higher
- ▶ Minimum 64 MB of memory
- ▶ Minimum 40 MB of free hard disk space
- ▶ Mouse

Please install DAQMaster before other ADLINK software for basic configuration and diagnosis. The ADLINK DAQMaster is a smart device manager that accesses ADLINK data acquisition products (refer to <http://www.adlinktech.com/MAPS/DAQ-Master.html>).

2.3 Installing AD-Logger

This section provides instructions on how to install AD-Logger in your system. Prepare the ADLINK AD-Logger CD that comes with the card package.


To install AD-Logger:

1. Place the ADLINK AD-Logger CD to the optical drive of the computer.
2. When the installation window appears, click on the AD-Logger installation button.

NOTE If Autorun is not enabled in your computer, explore the CD, and then double-click on the SETUP.EXE to display the installation window.

3. When installation is complete, simply launch AD-Logger to log data for further analysis.






2.4 Uninstalling AD-Logger

Uninstall AD-Logger using the “Add/Remove Programs” tool in the Control Panel in Windows.. Select AD-Logger from currently installed programs and click Change/Remove button to delete the software.

2.5 Launching the AD-Logger

To launch the AD-Logger from the Windows Start menu, click **Start >ADLINK>AD-Logger>AD-Logger**. The main AD-Logger window will appear.



3 Understanding AD-Logger

3.1 Main Menu



| Menu | Function |
|---------|-------------------------------------|
| File | System commands |
| Task | DAQ task commands |
| Setting | System configuration options |
| Viewer | View commands |
| Export | Export log data commands |
| Help | Online help and support information |

3.1.1 File Menu

The File Menu provides the following options:

| File | Function |
|---------------|--|
| New Task | Create a new DAQ Task |
| Open | Open a Task or Log file |
| New project | Create a new AD-Logger project to perform data acquisition |
| Open project | Open an existing AD-Logger project |
| Close project | Close current AD-Logger project |
| Save project | Save all current data acquisition task configurations into current project |
| Print | Print current Data |
| Print Preview | Preview current Data for printing |

3.1.2 Task Menu

The Task Menu provides the following options:

| Task | Function |
|-------------|---|
| New task | Launch the DAQPilot Interactive Dialog to create a new data acquisition task |
| Modify task | Launch the DAQPilot Interactive Dialog to modify The selected data acquisition task |
| Delete task | Delete an existing data acquisition task from the Task View Panel |
| Start tasks | Start to perform all data acquisition tasks on the Task View Panel |
| Stop tasks | Stop all data acquisition tasks on the Task View Panel |

3.1.3 Setting Menu

The setting menu provides the following options:

| Setting | Function |
|-----------------|--|
| Display | Provides the Display configurations of time domain which includes X-axis, Y-axis, Appearance and Channel settings. |
| FFT | Provides the Display configurations of frequency domain which includes X-axis, Y-axis, Appearance and Channel settings. |
| Recording | Enable/Disable the function of data acquisition task. The Log functions can be stopped by manual, by pre-defined sample and by time. The location to save log data can also be selected. |
| Alarm Condition | Enable/Disable the Alarm functions which could be above or below a constant value. |

3.1.4 Viewer Menu

The Viewer Menu provides the following options:

| View | Function |
|----------------|---|
| Graph Viewer | Enable/disable the time domain data display of the selected data acquisition task |
| FFT Viewer | Enable/disable the frequency domain data display of the selected data acquisition task |
| Status Viewer | Enable/disable the display of the system information, log task setting and hard disk space. |
| Message Viewer | Enable/disable the display of system commands and message. |

3.1.5 Export Menu

The Export Menu provides the following options:

| Export | Function |
|-------------|--|
| Excel | Export the logged data to a Microsoft Excel file |
| CSV | Export the logged data to a comma separated value file |
| Third-party | Export the logged data for the post-processing in third-party software, such as LabVIEW®, DIAdem, or MATLAB® |


3.1.6 Help Menu

The Help Menu provides the following options


| Help | Function |
|--------------------|--|
| AD-Logger Help | Get on-line help |
| Contact us | Get technical support |
| About AD-Logger | Display the ADLINK AD-Logger version and copyright statement |
| About my computer | Display the system information such as the operating system version, processor and memory usage status |
| Register AD-Logger | Form to input the license number for using a licensed version of AD-Logger |

3.2 AD-Logger Function

ADLINK AD-Logger is designed with six major function blocks that can be enabled/disabled individually for operations. Refer to the block diagram below.



TabSheet A for Task View; TabSheet B for History View













| Panels | Description |
|-----------------------|--|
| 1. Speed Buttons | Includes four major task operations and related functions (such as exporting data). |
| 2. Buffer Viewer | Display the buffer status. |
| 3. Task /History View | Display the information of existed DAQ task and history log. This part include two tabsheets : "Task Explorer" and "Logged Data" |
| 4. Status Viewer | Display system information including the task setting, available hard disk and the system resource. |
| 5. Data View | Display the logged data in time domain and frequency domain. |
| 6. Message View | Display the history commands and task status |

3.2.1 Speed Buttons

These speed buttons are designed with major task commands and exporting functions. The buttons will be dynamically enabled or disabled depends on the operation mode.



| Speed Buttons | Description |
|---|--|
|  Create Task | Launch the ADLINK DAQPilot interactive configuration dialog to create a new data acquisition task. AD-Logger is powered by DAQPilot, so you can finish DAQ application without any programming effort. |
|  Start | Start to perform the all data acquisition tasks |
|  Stop | Stop all data acquisition tasks |
|  Setting | Launch the setting form for configuration such as Graph, FFT, Log, Alarm and ADC. |
|  Modify | Launch ADLINK DAQPilot interactive configuration dialog to modify the existed data acquisition task. |
|  Recording | Enable/disable the recording function. |
|  FFT | Enable/disable the power spectrum view panel |
|  Excel | Export the logged data to an Excel file. |
|  CSV | Export the logged data to a comma separated value file. |
|  Third Party | Export the logged data for the post-processing in third-party software, such as LabVIEW®, DIAdem and MATLAB®. |

3.2.2 Buffer Viewer

AD-Logger provides a data buffer evaluation mechanism. The buffer evaluation mechanism will be automatically enabled to monitor and display the buffer status on the Buffer Viewer when you perform a DAQ task with recording function. The buffer status will be dynamically changed in real-time depending on system performance.



The Buffer View has following status:


| Buffer View Status | Description |
|--------------------|--|
| Blue Color | The system's performance is ample for data logging with the DAQ tasks. The buffer has more than 50 percent of available space when logging data. |
| Yellow Color | The buffer usage is sufficient with the the DAQ tasks. The buffer has 20 percent to 50 percent of available space when logging data. |
| Red Color | The buffer usage is running low with the DAQ tasks. The buffer has less than 20 percent of available space when logging data. |








3.2.3 Task Explorer/Logged Data Viewer

The Task/History view Panel is located on the left part of the AD-Logger main window. The View Panel displays the current DAQ tasks in the Tasks panel (page 15) and history log data in the Logged Data panel (page 16).

"Task Explorer" Tabsheet


The Tasks tabsheet displays the all DAQ tasks and related attributes in the project. The task with a blue background color is the selected task which displays logged data in the Data View Panel. You can click the task node to check the task status and double-click the task node to modify parameters via the pop-up configuration window.



| Icons | Description |
|---|---|
|  | DAQ task name. |
|  | DAQ tasks type. This icon will be dynamically changed depends on the DAQ task type. |
|  | DAQ device type. |
|  | Sample rate of the DAQ task. |
|  | Enable channel(s) of DAQ task. |
|  | Operation error message. |
|  | Alarm status |

"Logged Data" Tabsheet

The "Logged Data" tabsheet displays the logged file(s) which are classified by the task name and sorted by logged time. You can double click the node to display the logged data value in the Data View.




3.2.4 Status Viewer

The Status Viewer consists of three blocks. Each block is described as follows.

| Log Task | Log Condition | Log Range |
|---------------|---------------|-----------|
| DAQTask0.task | Stop by User | None |
| DAQTask3.task | Stop by User | None |

| Hard Disk | Total Size | Available Size |
|-----------|------------|----------------|
| C: | 44.756 GB | 4.4004 GB |
| D: | 29.745 GB | 13.569 GB |



| Data | Disk | Alarm |
|------|------|-------|
| | | |














| Status View | Description |
|-------------|--|
| Block 1 | Shows the selected log task(s) and its log condition. |
| Block 2 | Displays hard drive status |
| Block 3 | Indicates if the following status is enabled in AD-Logger. <ul style="list-style-type: none"> ▶ Data: Acquiring data if this label is blinking ▶ Disk: Recording to Disk if this label is blinking ▶ Alarm: Alarm indicator |

3.2.5 Data Viewer

The Data Viewer displays the logged data in both time and frequency domains. Initially, the selected DAQ task only displays time domain data. User can enable the frequency domain data on demand. Please refer to Section 3.2.1 (Speed Buttons).




The toolbars on the top on the time domain and frequency domain graph both provide the same function to control the data display. The functions are described as follows.


| Data Viewer Toolbars | Description |
|---|---|
|  Resume | The resume button enables tracking function on all axes. When tracking function is enabled, the axes will adjust their min and span values based on the tracking style. In addition to enabling tracking, all cursors will be hidden, and the axes min and span will be restored to their previous values when the axes tracking were initially disabled. |
|  Scroll (Axes) | When the Axes Scroll Mode button is enabled, you can drag the axis and scroll the view. When this button is selected, the Axes Zoom Mode button is correspondingly unselected. |
|  Zoom (Axes) | When the Axes Zoom Mode button is enabled, you can drag the axis and zoom the view. When this button is selected, the Axes Scroll Mode button is correspondingly unselected. |
|  Zoom out All Axes | When this button is clicked, all axes are zoomed out by a factor 2x. When this button is clicked, the tracking function on all axes will be disabled and the view data will be frozen. |
|  Zoom in All Axes | When this button is clicked, all axes are zoomed in by a factor 2x. When this button is clicked, the tracking function on all axes will be disabled and the view data will be frozen. |
|  Zoom Box | This button allows you to band a region in the Data Viewer for zooming into. The box can start at any point, but must be dragged to the lower right to define a region for zoom function. The zoom action will affect all axes. |
|  Data Cursor | This button shows or hides all data cursors. |
|  Copy to Clipboard | This button copies the current plot image to the clipboard. |
|  Save to File | This button brings up a Save dialog to save the plot image to a file. You can select from bitmap, metafile, or JPEG as the file type. |
|  Print | This button prints the plot image. |
|  Preview | This button launches the Print-Preview dialog before printing out the plot image. |

Data Cursor


The Data Cursor of the DataView has many useful functions which let you to check the data value on the DataView. You can click the

 button to enable the Data Cursor function.

When you enable the Data Cursor function, you can just drag and drop the green line in the middle of the DataView to any position. The x and y value of the Data Cursor will be displayed in real-time.



The Data cursor provides advanced configurations: you can right-click the mouse on the middle green line to launch the pop up menu (as shown below). You can see there are sixteen Data Cursors in each domain in the Data Viewer Panel. You can set all Data Cursors to only a specified channel at a different position, each Data Cursor to each channel, or any style you wish.



The popup menu of the Data Cursor contains the following settings.

| Menu | Description |
|---------|---|
| Channel | Set the Data Cursor to detect which channel you specify. |
| Style | The value of Data cursor can be configured to several styles. <ul style="list-style-type: none"> ▶ Value of x-y: Show both the X and Y axes values. ▶ Value of x: Only show the X-Axis value. ▶ Value of y: Only show the Y-Axis value. ▶ Period: Show a period value of two cursors on the X-Axis ▶ Peak to Peak: Show the difference in value between two peaks on the Y-Axis ▶ Frequency: Display the inverse of the instance along the X-Axis or the frequency. |
| Options | Use Channel Color: Set the cursor's color to channel color. |
| | Hide Hint on Release: Hide all value styles. |
| | Flip alignment: Switch value label to the opposite position. |

3.2.6 Message Viewer

The Message Viewer logs a history of operation command(s) and system messages.

```
< Task > Start DAQ Task(s) at 18:24:50  
< Task > Stop DAQ Task(s) at 18:24:52
```

The Message Viewer includes the following three types of log messages:


| Prefex | Description |
|---------------|---|
| <Task> | Regarding a DAQ task operation. |
| <Config> | Regarding Data Viewer, Log, and Alarm configurations. |
| <Buffer> | Regarding the Buffer Mechanism status. |


4 Starting AD-Logger


When you launch AD-Logger, there is a default DAQ Task with pre-defined continuous analog input function which works with a Simulated Device. You can easily modify the task for further configurations.

4.1 Configure a DAQ Task


4.1.1 Modify Task

1. Choose the task node that you want to modify.
2. Click the Modify button  or right-click the task node and select “modify task” in the pop-up menu to launch the DAQPilot configuration dialog. The DAQPilot interactive configuration dialog will guide you in configuring the DAQ task.





- The Task name will be shown in the DAQPilot interactive configuration dialog as shown in Step 1. If you need to change the Task name, you need to modify it first on the task node on the tree.







4. Select the supported device, then configure the channels



The DAQPilot interactive configuration dialog allows you to select the device and define the corresponding channel settings. This configuration window enables you to easily set the Range and RefGround from the drop-down combo box. For more details about using the DAQPilot interactive configuration dialog, please refer to Chapter 3 of the DAQPilot user manual. More information can also be found at <http://www.adlinktech.com/MAPS/DAQPilot.html>


6. Testing the Task

After setting the task parameters, you can use the DAQPilot built-in test panel to check whether the task parameters are in range and the task works well. Click  to begin to test the task. To stop testing, click . You can click  to change the setting of instant test panel.




After a quick task verification, you can click the **Finish** button to complete defining your DAQ task and close the configuration interactive dialog and return to the AD-Logger main window.

4.1.2 Create Task

Click the  button to launch the DAQPilot interactive configuration dialog to create a new DAQ task.

When the DAQPilot interactive dialog appears, right-click the mouse to select the task type/function; then select the task sub-type from the pop-up menu. AD-Logger supports analog and digital input functions as shown in the figures below.






The task types AD-Logger supports are listed as follows.

| Function | Support Mode |
|------------------------|------------------|
| Analog Input Function | Continuous Mode |
| | Single Shot Mode |
| | Polling Mode |
| Digital Input Function | Continuous Mode |
| | Single Shot Mode |
| | Port Mode |
| | Line Mode |


After choosing the task type, please refer to section 4.1.1- to modify the selected task for following setting illustration.

4.1.3 Delete Task

In the Task Tree, you can right-click the mouse on the task node to launch a pop-up menu and choose **Delete Task**.



If there is no task in the **Task tree**, the AD-Logger will automatically be settled in disabled mode. A DAQ task must be created or loaded.




4.2 Setting DAQ Condition

After creating a new DAQ task, the AD-Logger will automatically open the setting form to configure the Display, FFT View, Recording Conditions and Alarm Conditions settings. If you want to launch the setting form, you can just click the task node and click



setting button.




The screenshot shows the 'Setting Page' dialog box for AD-Logger. The title bar reads 'Setting Page'. The main area features the 'ADLOGGER' logo at the top. Below the logo is a tabbed interface with four tabs: 'Display' (selected), 'FFT', 'Recording', and 'Alarm Condition'. The 'Display' tab is active and contains several sections:

- X-Axis Setting:** Includes 'View Number(Samples)' (dropdown: 1024), 'Tracking' (checked), 'Precision' (dropdown: 3), and 'Scroll Bar' (unchecked). Below this is the 'X-Axis Title' section with 'Text' (input: Samples), 'Font' (button), 'Show' (checked), and 'Rotate' (unchecked).
- Y-Axis Setting:** Includes 'Max' (input: 10), 'Tracking' (checked), 'Precision' (dropdown: 5), and 'Min' (input: -10). Below this is the 'Y-Axis Title' section with 'Text' (input: Voltage), 'Font' (button), 'Show' (checked), and 'Rotate' (unchecked).
- Appearance:** Includes 'Background Color' (black), 'Grid Lines' (checked, color green), 'Major Style' (Solid), and 'Minor Style' (Solid).
- Channel Setting:** Includes 'X Axes' (unchecked), 'Y Axes' (checked), 'Y-Max' (checked), 'Y-Min' (checked), 'ch0' (dropdown), and 'Color' (red).

At the bottom of the dialog are 'OK', 'Cancel', and 'Apply' buttons.


The following sections will describe the setting forms.

4.2.1 Display Settings



| item | Description |
|-----------------|--|
| View Number | Set the number of data samples you want to display on the time domain Data Viewer. |
| Tracking | Enable/disable the tracking function. When the tracking function is enabled, the axes will adjust their min and span values based on the tracking style. |
| Scroll Bar | Enable/disable scroll bar. |
| X-Axis Title | Set the X-Axis title. |
| Max/Min | Set the Y-Axis maximum/minimum display value. |
| Y-Axis Title | Set the Y-Axis title. |
| Appearance | Configure the color of background, grid lines and the style of grid lines. |
| Channel Setting | Enable/disable the display of X and Y-Axis values in legend and set the related channel color. |

4.2.2 FFT setting



| item | Description |
|-----------------|--|
| Enable | Enable/disable to perform the FFT calculation when capturing data. |
| View Number | Set the number of data samples to perform FFT calculation and display the result on the frequency domain DataView. |
| Tracking | Enable/disable the tracking function. When the tracking function is enabled, the axes will adjust their min and span values based on the tracking style. |
| Scroll Bar | Enable/disable the function of scroll bar. |
| X-Axis Title | Set the X-Axis title. |
| Max/Min | Set the Y-Axis maximum/minimum display value. |
| Y-Axis Title | Set the Y-Axis title |
| Appearance | Configure the color of background, grid lines and the style of grid lines. |
| Channel Setting | Enable/disable the display of X and Y Axis values in legend and set channel color. |

4.2.3 Recording Condition

Display | FFT | **Recording** | Alarm Condition

Data Log

Log to Disk Enable
 Disable

Recording Condition

Stop by user
 By Sample Number
 By Time Interval

By Sample Number

Number of Samples

By Time Interval

Start

Stop

Log Data Path

History Data Path:
 C:\Documents and Settings\Leslie\My Documents\AD-Logger\Log\

- ADLINK
- AD-Logger
- CheckSN

| item | Description |
|---------------------|---|
| Data Log | Enable/disable to log DAQ data to disk. |
| Recording Condition | Set a condition to automatically stop logging file to disk. |
| By Sample Number | Set the amount of sample to log data to disk. |
| By Time Interval | Set the time range to log data to disk. |
| Set Location | Set a path to store logged data. |

4.2.4 Alarm condition


Display | FFT | Recording | Alarm Condition

Alarm Condition Settings

| Channel NO | Alarm Condition | Value (v) | Status |
|------------|-----------------|-----------|--------|
| Ch0 | Disable | 0 | Normal |
| Ch1 | Disable | 0 | Normal |


| Item | Description |
|--------------------------|---|
| Alarm Condition Settings | You can enable/disable the alarm condition and set trigger value for each channel of the DAQ task. If AD-Logger detects the trigger value you set, the Alarm warning will show in the Status Viewer . |

4.3 Start Data Acquisition

After you configure the DAQ parameters in section 4.2, you can click  button in the AD-Logger main window to start data acquisition based on the pre-defined DAQ task.

Display Log Enable Status

If the task start with the recording function. (Section 4.2.3), the **Buffer Monitor Bar** will display the available memory status of buffer (see figure below). When the AD-Logger completes the logging task, the **Buffer Monitor Bar** will switch to a disabled status.




Display Alarm Status


If the task starts with the alarm function (Section 4.2.4), AD-Logger will keep detecting the alarm condition during the data logging until you click the **Stop** button. If AD-Logger detects the trigger condition, AD-Logger will automatically stop the DAQ procedure (figure below). The related task in the Task View Panel will also show the **alarmed** status with a red color.

| Log Task | Log Condition | Log Range |
|--|---------------|----------------|
| | | |
| | | |
| | | |
| Hard Disk | Total Size | Available Size |
| C: | 48.834 GB | 18.392 GB |
| D: | 184.05 GB | 24.32 GB |
| Start Logging Alarm | | |

You can launch the setting form and switch to the **Alarm Condition** tabsheet to configure the Alarm conditions.




4.4 Stop and Export Data for post-processing

Click the  button to stop the task(s). If you already have data logged in the system, the log files could be managed in the **Logged Data tabsheet**.

Switch to **Logged Data tabsheet**; double click the selected log file to display the data in the **DataView Window**.


If the sample number is more than 1024, the scrollbar can be used to switch the data block for display.





5 Exporting Functions

The AD-Logger log data is in binary files with private data format (Appendix). You can manage log file on AD-Logger "**Logged Data**" **tab**sheet or use the following exporting functions. The AD-Logger provides several data formats which help you to do analysis and post-processing in the third-party applications.

5.1 Export Data to Excel for post processing


1. Launch AD-Logger and select the **Logged Data** **tab**-sheet.
2. Double click the log file you want to export.
3. Click the  button to show **Export Data** setting form.







4. Specify the file name and file path by **Browser** button.
5. Configure the **Range Option** and click the **Export button**. The exported data will be automatically loaded and displayed in the Excel tabsheet.

5.2 Export Data as a CSV file for Excel for post processing

1. Launch AD-Logger and Switch to the **Logged Data** tab-sheet
2. Double click the log file you want to export.
3. Click the  button to show **Export Data** setting form.






4. Specify the file name and file path by **Browser** button.
5. Configure the **Range Option** and click the **Export** button. The data will be exported to a CSV file in the path you specified.

5.3 Export Data into LabVIEW for post processing

This section will demonstrate how to perform Data Acquisition with ADLINK PCI-9221 and do FFT analysis in LabVIEW. Before the post-processing captured in LabVIEW, you need to use AD-Logger **Export** function to convert the AD-Logger file to LabVIEW compatible format. The process includes three steps:

- ▶ Configure DAQ device and Set log conditions.
- ▶ Start the data acquisition and Export captured data to LabVIEW.
- ▶ Use LabVIEW to do FFT analysis

1. Configure DAQ device and parameters.

Launch AD-Logger and click  Modify DAQ task button to open DAQPilot interactive configuration dialog. You can configure DAQ device and relative parameters in the following setting dialogs.






<Interactive Configuraiton Dialog STEP 1:
Select Device & Channel>




<Interactive Configuraiton Dialog STEP 2:
Timing/Trigger Setting >




<Interactive Configuraiton Dialog STEP 3: Get Instant Result>


After quick task verification, you can click **Finish** button to finish the definition of your DAQ task then close the configuration interactive dialog and return to the AD-Logger main window.

2. Set log conditions

Click the  Project Setting button to open the AD-Logger setting form.




Change to Log Tab sheet and finish following steps.




- ▶ Step 1: Set Enable data Log>
- ▶ Step 2: Set Data Log Condition by Sample Number>
- ▶ Step 3: Set 16384 Samples to log>
- ▶ Step 4: Set the Path to save log file to>
- ▶ Step 5: Click OK button to return AD-Logger Main Window>


3. Start to DAQ and Export data to LabVIEW file


After configuring DAQ and log parameters, click  Start button the AD-Logger will start to perform DAQ; the log file will be saved to the path you specified.

Click “Logged Data” change to See history data




The log files will be sequentially list by task name and time in the **Logged Data** tabsheet. Double click the file name in the tree, AD-Logger will display the data value in the Time Domain Data View; then the **Export** buttons will be enabled.



Click the  button to show the **Export Data** setting form.


- ▶ **Step 1:**
Choose LabVIEW data format
- ▶ **Step 2:**
Set exported file name and path
- ▶ **Step 3:**
Set ALL range data to export
- ▶ **Step 4:**
Click Export button




4. Use LabVIEW to do advanced analysis

Load the exported LVM file into LabVIEW.

- ▶ **Step 1: Open a Blank VI in the NI LabVIEW software.**
- ▶ **Step 2: Right click and place a “Read From Measurement File” Express VI in the Block Diagram.**



- ▶ **Step 3: In the Configure “Read From Measurement File” form, specify the file location that you want to import.**
- ▶ **Step 4: Click “Read File Now” button can preview the data value then close form by click OK button.**




- ▶ **Step 5: Right click and place a “Spectral Measurements” Express VI of Signal Analysis in the Block Diagram. The “Spectral Measurements” setting form will be opened.**


Example: Using FFT function to calculate power spectrum result.

Input Signal = 1022.34 Hz

Sampling rate = 250 KHz



- **Step 6:** There are four measurement functions in the Configure Spectral Measurements , in this case we chose “Power spectrum” function.



Configure Spectral Measurements

Selected Measurement

- Magnitude (RMS)
- Magnitude (Peak)
- Power spectrum
- Power spectral density

Result

- Linear
- dB

Window

Hanning

Averaging

Mode

- Vector
- RMS
- Peak hold

Weighting

- Linear
- Exponential

Number of Averages

10

Produce Spectrum

- Every iteration
- Only when averaging complete

Phase

- Unwrap phase
- Convert to degree

Windowed Input Signal

Amplitude

Time

Magnitude Result Preview

Magnitude

Frequency


Phase Result Preview

Phase (rad.)


Frequency

OK Cancel Help


► **Step 7: Place a “Waveform Graph” VI in the Front Panel**




► **Step 8: Finish following signal links in the Block Diagram.**




- ▶ **Step 9: Right click on the Waveform Graph VI and choose property of the pop-up menu.**




- ▶ **Step 10: In the Scales tab, set Name of the X-Axis and Multiplier of Scaling Factors(sample rate).**



- **Step 11: In the Plots tab, enable the following option.**






- **Step 12: Switch to the Block Diagram, start to execute the program will display the power spectrum result.**



5.4 Export Data into DIAdem for post processing

1. Launch AD-Logger and Switch to the **Logged Data** tab-sheet.
2. Double click the log file you want to export.

3. Click the  button to show the **Export Data** setting form.





The Export Data dialog box is shown with the following settings:

- Data Format:** Excel CSV LabView DIAdem MATLAB
- File Name:** D:\Unlitle.tdms (with a Browser button)
- Range Option:** Screen All Range
- Range:**
 - Sample Unit: Start 1, End 225000
 - Time Unit: End 225000


Buttons: Export, Close

4. Assign the file name and file path.
5. Click the DIAdem data format.
6. Configure the **Range Option** and click the **Export** button. The exported data can be found in the path you specified.
7. Load the exported data through the **DIAdem NAVIGATOR**.
8. Drag and drop the **Group Name** of log file into the **Data Portal** window. Then the Group Name will be added in the **Data Portal** for further operations.



9. Switch to the VIEW window of DIAdem, select a 2D Axis System in the worksheet.

10. Drag and drop Channel 0 and Channel 1 to the 2D Axis System. The data value will be displayed in the graph.





5.5 Export Data into MATLAB post processing

This section will demonstrate how to perform Data Acquisition with ADLINK PCI-9221 and do analysis in MATLAB. Before the post-processing captured in MATLAB, you need to use the AD-Logger **Export** function to convert the AD-Logger file to MATLAB compatible format. The process includes three steps:

- ▶ Configure DAQ device and Set log conditions.
- ▶ Start the data acquisition and Export captured data to MATLAB.
- ▶ Use MATLAB to do advanced analysis

1. Configure DAQ device and parameters.

Launch AD-Logger and click  Modify DAQ task button to open DAQPilot interactive configuration dialog. You can configure DAQ device and relative parameters in the following setting dialogs.






<Interactive Configuraiton Dialog STEP 1:
Select Device & Channel>




<Interactive Configuraiton Dialog STEP 2:
Timing/Trigger Setting >




<Interactive Configuraiton Dialog STEP 3:
Get Instant Result>

After quick task verification, you can click the **Finish button** to finish the definition of your DAQ task then close the configuration interactive dialog and return to the AD-Logger main window.

2. Set log conditions

Click the  **Project Setting** button to open the AD-Logger setting form.




Change to Log Tab sheet and finish following steps.




- ▶ **Step 1: Set Enable data Log**
- ▶ **Step 2: Set Data Log Condition by Sample Number**
- ▶ **Step 3: Set 16384 Samples to log**
- ▶ **Step 4: Set the Path to save log file to**
- ▶ **Step 5: Click OK button to return AD-Logger Main Window**


3. Start to DAQ and Export data to MATLAB file


After configuring DAQ and log parameters, click  Start button the AD-Logger will start to perform DAQ; the log file will be saved to the path you specified.

Click “Logged Data” change to History Data View




The log files will be sequentially list by task name and time in the Logged Data tabsheet. Double click the file name in the tree, AD-Logger will display the data value in the Time Domain DataView; then the Export buttons will be enabled.



Click the  button to show the **Export Data** setting form.


- ▷ **Step 1: Choose MAT-LAB data format**
- ▷ **Step 2: Set exported file name and path**
- ▷ **Step 3: Set ALL range data to export**
- ▷ **Step 4: Click Export button**



4. Use MATLAB to do advanced analysis

Load the exported CSV file into MATLAB.

- ▷ **Step 1: Set the Current Directory to the exported file saved.**
- ▷ **Step 2: Type “load D9221Data.csv” in the Command Window**
- ▷ **Step 3: An array created with the same name of the exported file in the Workspace.**





- **Step 4: You can use this data array to do the advanced analysis like following pictures**

Example: Using FFT function to calculate power spectrum result.

Input Signal = 1022.34 Hz

Sampling rate = 250 KHz

The source code is listed in the next page.




```

load D9221Data.csv
Fs = 250000; % Sampling frequency
fin = 1022.34;
numpt = 16384; % Length of signal
notdc = 3;

figure(1);
plot(D9221Data);
title('Signal Input');
xlabel('Points');ylabel('Amplitude (V)');

Doutw = D9221Data.*hann(numpt);
Dout_spect = fft(Doutw);
Dout_dB = 20*log10(abs(Dout_spect));
% Recalculate to dB
spectP = (abs(Dout_spect)).*(abs(Dout_spect));
% Determine power spectrum

FFT_freq = [0:numpt/2-1].*Fs/numpt;
FFT_spectrum = Dout_dB(1:numpt/2);
figure(2);
% Plot single-sided amplitude spectrum.
plot(FFT_freq,FFT_spectrum)
title('Power Spectrum of Input Signal')
xlabel('Frequency (Hz)')
ylabel('Magnitude(dB)')
pll_title = ['Input Signal = ', num2str(fin), '
            Hz @ ', num2str(signal_dBFS),
            ' dBFS', ' , Sampling rate = ', num2str(Fs/
            1000), ' KHz'];
title(pll_title);

```


6 Appendix

6.1 AD-Logger .DAT File Format

This appendix describes the file format of the .dat files logged through file AD-Logger file system. The data file includes five parts, ADLINK DASK Header, ChannelRange, Data Block, AD-Logger Header and ChannelRange. The file structure is shown in the figure below:

| |
|------------------------|
| DASK Header |
| ChannelRange(Optional) |
| DAQ data |
| AD-Logger Header |
| ChannelRange(Optional) |

6.1.1 DASK Header

The DASK header part records the information related to the stored data and its total length is 60 bytes. The data structure of the file header is as follows:

| DASK Header Length: 60 bytes | | | |
|-------------------------------------|---------------|---------------------|---|
| Elements | Type | Size (bytes) | Comments |
| ID | char | 10 | file ID ex. ADLinkDAQ1 |
| card_type | short | 2 | card Type ex. PCI-7250, PCI-9112 |
| num_of_channel | short | 2 | number of scanned channels ex. 1, 2 |
| channel_no | unsigned char | 1 | channel number where the data read from (only available as the num_of_channel is 1) ex. 0, 1 |
| num_of_scan | long | 4 | the number of scan for each channel (total count / num_of_channel) |
| data_width | short | 2 | the data width 0: 8 bits, 1: 16 bits, 2: 32 bits |
| channel_order | short | 2 | the channel scanned sequence 0: normal(ex. 0-1-2-3) |
| ad_range | short | 2 | the AI range code Please refer to ADLINK DASK Function Reference Appendix B ex. 0 (AD_B_5V) |
| scan_rate | double | 8 | The scanning rate of each channel (total samplingrate/ num_of_channel) |
| num_of_channel_range | short | 2 | The number of ChannelRange* structure |
| start_date | char | 8 | The starting date of data acquisition ex. 12/31/99 |
| start_time | char | 8 | The starting time of data acquisition ex. 18:30:25 |
| start_millisecond | char | 3 | The starting millisecond of data acquisition ex. 360 |
| reserved | char | 6 | The AD-Logger supports log files which the first byte of reserved element is "A". Others no used. |

*If the num_of_channel_range is 0, the ChannelRange block won't be included in the data file.

6.1.2 ChannelRange

The ChannelRange part records the channel number and data range information related to the stored data. This part consists of several channel and range units. The length of each unit is 2 bytes. The total length depends on the value of num_of_channel_range (one element of the file header) and is calculated with this formula:

$$\text{Total Length} = 2 * \text{num_of_channel_range bytes}$$

The data structure of each ChannelRange unit is listed below:

| ChannelRange Length: 2 bytes | | | |
|------------------------------|------|--------------|---|
| Elements | Type | Size (bytes) | Comments |
| channel | char | 1 | scanned channel number ex. 0, 1 |
| range | char | 1 | the AI range code Please refer to ADLINK DASK Function Reference Appexdix B ex. 0 (AD_B_5V) |

6.1.3 Data Block

The data is written to file in a 16-bit binary format, with the lower byte first (little endian). For example, the value 0x1234 is written to disk with 34 first followed by 12. The total length of the data block depends on the data width and the total data count.

The file is written in Binary format and may not be read by normal text editor. You can use any binary file editor to view it or the functions used for reading files (such as fread) to get the file information and data value. PCIS-DASK provides the DAQCvt utility to convert the binary file. Refer to the PCIS-DASK user manual for details

6.1.4 AD-Logger Header

The AD-Logger header part records the information related to the stored data and its total length is 64 bytes. The data structure of the file header is as follows:

| AD-Logger Header Length: 64 bytes | | | |
|-----------------------------------|---------------|--------------|--|
| Elements | Type | Size (bytes) | Comments |
| ID | char | 10 | file ID ex. ADLogger1 |
| task_type | unsigned long | 4 | The DAQPilot DAQ task type ex. Continuous Wave Acquisition |
| card_type | short | 2 | card Type ex. PCI-7250, PCI-9112 |
| num_of_channel | short | 2 | number of scanned channels ex. 1, 2 |
| channel_no | unsigned char | 1 | channel number where the data read from (only available as the num_of_channel is 1) ex. 0, 1 |
| num_of_scan | long | 4 | the number of scan for each channel (total count / num_of_channel) |
| data_width | short | 2 | the data width 1: 8 bits, 2: 16 bits, 4: 32 bits |
| channel_order | short | 2 | the channel scanned sequence 0: normal(ex. 0-1-2-3) |
| ad_range | short | 2 | the AI range code Please refer to ADLINK DAQPilot User Manual ex. 0 (AD_B_5V) |
| scan_rate | double | 8 | The scanning rate of each channel (total samplingrate/ num_of_channel) |
| num_of_channel_range | short | 2 | The number of ChannelRange* structure |
| start_date | char | 8 | The starting date of data acquisition ex. 12/31/99 |
| start_time | char | 8 | The starting time of data acquisition ex. 18:30:25 |
| start_millisecond | char | 3 | The starting millisecond of data acquisition ex. 360 |
| reserved | char | 6 | No used. |

*If the num_of_channel_range is 0, the ChannelRange block won't be included in the data file.

6.1.5 ChannelRange

The ChannelRange part records the channel number and data range information related to the stored data. This part consists of several channel and range units. The length of each unit is 2 bytes. The total length depends on the value of num_of_channel_range (one element of the file header) and is calculated with this formula:

Total Length = 2 * num_of_channel_range bytes

The data structure of each ChannelRange unit is listed below:

| ChannelRange Length: 2 bytes | | | |
|------------------------------|------|--------------|---|
| Elements | Type | Size (bytes) | Comments |
| channel | char | 1 | scanned channel number ex. 0, 1 |
| range | char | 1 | the AI range code Please refer to ADLINK DAQPilot User Manual ex. 0 (AD_B_5V) |